

EZ675-5KM

Model Rocket Altimeter

User's Manual

© Mike Dorffler
2418 Greenway Circle
Canon City, Colorado 81212
USA

mdorffler@bresnan.net



Altitude Measurement

The EZ675-5KM altimeter determines peak altitude reached by comparing the lowest barometric pressure measured during flight to the launch site barometric pressure. Atmospheric pressure decreases as altitude increases. The software algorithm within the microprocessor constantly samples the atmospheric pressure as the rocket ascends. A change from decreasing to increasing pressure indicates that a peak in altitude has been reached and the rocket is then descending. The two barometric pressures are then mathematically translated to altitude in feet. The altitude at the launch site is subtracted from the maximum altitude, and the difference is reported as the flight altitude reached.

The mathematical routines used in the EZ675-5K code to first measure and then convert atmospheric pressure to altitude are quite sophisticated and lengthy. First, the Microchip microprocessor code algorithm measures the output voltage of the MPXH6115 pressure sensor using a 12-Bit A/D (Analog to Digital) converter. The A/D count is then converted to a kPa value X 100. The altitude is then computed using the kPa value;

As used in the EZ675-5K code;

$$\text{kPa} = ((\text{A/D count} * 2713) / 1000) + 1055$$

Example using the 12-Bit A/D count of 3234 retrieved using EZ675-5K code;
 $\text{kPa} = ((3234 * 2713) / 1000) + 1055 = 9828 \text{ (98.28)}$

Compare to kPa calculated from Motorola MPXH6115 specification;
 $\text{kPa} = ((3234 / 4096) + 0.095) / 0.009 = 98.28$

Altitude is computed within the EZ675-5K code using the accepted NOAA equation;

$$\text{Altitude in feet} = (1 - (\text{kPa}/101.325)^{0.190284}) * 145366.45$$
$$\text{Altitude for a kPa of } 98.28 = 840.6 \text{ feet}$$

If we use 2 consecutive 12-Bit A/D counts we can compute the typical resolution using the algorithms used in the EZ675-5K code;

$$\text{A/D Count} = 2947 = 90.50\text{kPa} = 3092 \text{ feet}$$

$$\text{A/D Count} = 2948 = 90.52\text{kPa} = 3084 \text{ feet}$$

$$\text{Resolution} = 8 \text{ feet per A/D Count @ } \sim 3000 \text{ feet ASL}$$

Altimeter Operation

When the altimeter is first turned on, the altitude reached in the previous flight is retrieved from the internal EEPROM memory and reported twice. The altitude was stored in the internal EEPROM as soon as the value was calculated during the flight. This feature is

intended to preserve the flight result if the battery dislodges upon a hard landing, or if the altimeter cannot be recovered before the battery voltage drops below 6 volts.


The ground elevation pressure is then sampled each second during a 16 second wait period. A running total is accumulated and kept with each sample. The resulting total is then averaged and saved as the launch site pressure.

With the launch site pressure established, the microprocessor code algorithm then looks for a sudden decrease in pressure equal to an increase in altitude of 100 feet (30 meters). When the 100-foot threshold is exceeded, the code is satisfied a launch has occurred.

The launch threshold test is made at 1.5 second intervals and is indicated by a short audible 'beep'. Note that it is not necessary that the EZ675-5K be in its final installed position inside the rocket payload section prior to launch for the launch detect testing to work correctly. The precision pressure sensor will always correctly measure whether the 100 foot altitude threshold has been reached. The user can complete the altimeter installation in the rocket, prep the model for flight, install the model on the pad, and attach the ignition clips to the igniter, and then proceed with launch countdown without falsely triggering the threshold detect.

Once the 100-foot threshold has been exceeded after launch, the barometric pressure is continuously sampled at 100 millisecond (1/10 second) intervals. Because the pressure decreases as the rocket ascends, each reading will be less than the previous reading. As the rocket slows and approaches peak altitude, the pressure differences begin to diminish and eventually reach zero. Peak altitude is determined when the present pressure sample becomes greater than the previous sample.

The launch site pressure is then converted to feet as well as the value detected at peak altitude. The ground altitude is subtracted from the peak altitude and is stored in the EEPROM. The circuitry then begins beeping out this value as the altitude reached this flight. The beep-out will continue until the battery is removed.



The Top Side EZ675-5K Components

Power For The Altimeter

The EZ675-5K altimeter is powered by a standard 12 volt "N" size remote battery. Appropriate part numbers are Duracell MN21/23, GP A23, Energizer A23, and Radio Shack 23-144. Please do not attempt to use any other type of battery with the EZ675-5K altimeter.

We hope the user will always install the battery correctly. If however it is inadvertently installed backwards, a reverse protection diode is included in the circuitry so that the unit will not be harmed. Some A23 manufacturers use a black plastic disk at the negative end, and a red disk for the positive end. All manufacturers mark the polarities on the exterior of the battery. Always be careful to install the battery with the negative end against the battery holder spring.

To install the battery -

Hold the altimeter on its edges with the thumb and fore finger of one hand. Push the negative end of the battery into the battery holder and against the spring. Use the end of your other thumb to apply pressure on the positive end of the battery to compress the spring, and then rock the battery into the proper holder position.

To remove the battery -

Use your thumbnail to grip the edge of positive battery end. Apply downward pressure on the battery and then rock it out of the holder.

Always remove the battery from the holder after each flight. This is to both preserve battery life, and to keep the molded battery holder from being deformed over time. Leaving the battery in place and using a small insulator inserted at either battery end as a 'switch' is not recommended.

Battery Life -

A cautionary note regarding the A23 battery; The EZ675-5K draws a continuous 6 ma of current. This translates to roughly 8 hours of continuous use from a fresh battery. Assuming a span of 30 minutes of use from the point the battery is installed, the altimeter is flown and recovered and the battery removed, the battery will provide 16 flights of use. Shorter use times will yield a greater number of flights per battery. If in doubt whether the battery has adequate power remaining for another flight, measure the voltage with the battery in place. If the voltage is greater than 7.0 volts, the battery is good to use.

Battery and Altimeter Storage -

We recommend that both the altimeter and battery be physically protected from damage when not in use. One simple method is to remove the battery and store battery and altimeter in separate plastic pill bottles. Screw-cap are better than snap-lids for this purpose. Use a length of bubble wrap around each in their respective bottles for damage protection during transport in a flight box. Do not use a 'soft' material for wrapping around the altimeter. Loose particles of paper, foam, and the like can separate and enter the pressure sensor port causing potential damage.

General Operation Notes

How the Altitude Is Reported - Pre-Loaded Count _____

Your unit has been shipped with a pre-loaded altitude achieved during the final checkout. That value is written above, and is saved in the EEPROM memory. As previously noted, this value will be beeped out twice the first time the altimeter is powered up. This 'practice' value allows the user to familiarize himself with the way the audible count sounds out the altitude. The battery can be removed and re-installed as many times as the user wishes to hear the count. This count will remain in memory serving as the previous flight altitude until the altimeter is flown. Just remember to wait about 10 seconds between removing the battery and re-installing it during each practice run.

Always remember that the code is written so that the battery can be removed immediately after the saved altitude is read out. It is not necessary to wait though the total pre-launch sequence to remove the battery to replay the count.

The same method for hearing the stored flight altitude count is true after any flight. In the event the user has difficulty reading the stored altitude, simply remove the battery, wait about 10 seconds, and re-install the battery. The altimeter will re-start, and the altitude will be sounded out twice more. Again, this can be repeated as many times as desired as the stored altitude will only change after the completion of a new flight.

How the Altitude is reported by the Audio Transducer -

The individual digits of the flight altitude result are always reported in the same manner. A long low transducer tone indicates the sequence start. The individual numbers are then reported beginning with the first of a maximum of 5 digits. A flight to 367 feet for example, will report only these 3 digits. A flight to 2,432 feet will report 4 digits, and a flight to 11,765 feet will report 5 digits. If the EZ675-5K has been built for Metric operation, the maximum number of digits will be 4. A short pause occurs between digits to isolate them audibly from one another.

Any leading zeros are not reported. The 367 foot flight example will begin with the 3, or 'hundreds' digit, not with 2 zeros for the missing 'ten-thousands' or 'thousands'. The 2,432 example will begin with the 2 at the 'thousands' digit, and the 11,765 feet example will begin with the first 1 at the 'ten-thousand' digit.

As an example, a measured altitude of 1024 will be reported as follows:

Long low tone beep – Sequence Start

Silent Pause

Beep - (1) thousands of feet

Silent Pause

Beeeeeeep – (0) hundreds of feet

Silent Pause

Beep-Beep – (2) tens of feet
Silent Pause
Beep-Beep-Beep-Beep – (4) ones of feet

Wait 5 seconds then the sequence is repeated -

Digits are reported simply as:

0 -- Beeeeeeeep

1 – Beep

2 – Beep-Beep

3 – Beep-Beep-Beep

4 – Beep-Beep-Beep-Beep

5 – Beep-Beep-Beep-Beep-Beep

6 – Beep-Beep-Beep-Beep-Beep-Beep

7 -- Beep-Beep-Beep-Beep-Beep-Beep-Beep

8 -- Beep-Beep-Beep-Beep-Beep-Beep-Beep-Beep

9 -- Beep-Beep-Beep-Beep-Beep-Beep-Beep-Beep-Beep

Installing the Altimeter in your Rocket -

The EZ675-5K needs to be placed in a payload section forward of the main power section of your rocket. The payload section must be built so that the interior is totally isolated from any ejection gases from the motor. Failure to do so may allow the heat and pressure of the ejection charge to penetrate the payload section, and damage or destroy the pressure sensor.

Remember, the key design element for proper altimeter operation is the ability for it to 'breathe' properly. The code samples the atmospheric pressure 10 times per second as the rocket ascends. The payload section must be properly vented to allow the internal payload section pressure to rapidly equalize to the outside pressure. The way this is accomplished is to vent the payload section with an array of equally spaced through-holes. The holes allow a quick flow of pressure differences to either enter or escape the payload section during rocket ascent and descent. The EZ675-5K will fail to properly measure flight altitude if it cannot quickly track the changes in atmospheric pressure.

There are other payload design considerations to bear in mind. Laminar air flow will always be disturbed by any break along the exterior shape of the rocket. This means that air turbulence is induced along the exterior surface of a model rocket at every radial body joint, or break along its length. The worst of these occurs at the joint where the nose cone fits into the forward end of the rocket. Unfortunately, this is very nearly where we place the altimeter that is dependant on pressure equalization to function correctly.


The work-around for this problem is to place the equalization holes for the altimeter a minimum of 3 calibers (a caliber is 1.0 body diameter) back from the nose cone mating joint. As an example, the pressure equalization holes for an Estes BT-50 tube should be a minimum of 3" back from the nose cone joint, regardless of the length of the nose cone.

Constructing an EZ675-5K Test Payload Section –


We recommend that the new user of an EZ675-5K build a simple 'C'-powered Estes BT-50 sized test flight model. The purpose is to learn how to use the altimeter with a minimum of motor expenditures. The following illustrations show how to construct a BT-50 sized payload section to fly the altimeter with any number of standard BT-50 sized Estes kits, including the standard Alpha. After a few test flights, the user can then design and build other payload section configurations for other sized models.

Standard BT-50 Payload Section Construction –


1. Cut a length of Estes BT-20 tube to 2.78" in length.
2. Pierce the tube in 3 places, spaced at 120 degrees, 0.35" from one end of the tube.
3. Use a 1/8" drill bit to carefully round out each pierced hole. Apply thin cyanoacrylate glue around the edge of each hole and allow to cure. Then lightly sand the interior and exterior surfaces of the tube at the hole edges to make them nice and crisp. Run the drill bit through the holes again to remove any fuzz.
4. Insert an EB-20A engine block even with the same end of the tube, and bond in place using the thin cyanoacrylate adhesive.



5. Bond an Estes AR-2050 adapter ring with its rear edge 3/8" from the end of the tube with the engine block.
6. Bond another AR-2050 adapter ring even with the other end of the tube.




7. The base body tube fitting for this payload section uses one of the 2 needed Estes PIN-50Y plastic nose cone inserts. The fit will be too loose in the BT-50 section without modification. First cut a 1/2" length of BT-50, then cut out a 1/8" wide section on one side. This will make a spacer that corrects the loose fit of the PIN-50Y.
8. Wrap and bond the slit tube around one of the PIN-50Y adapters. Make sure the edges of both parts match.
9. Cut a disk of 1/16" plywood or very hard balsa to make a slide fit in a BT-50 tube. This will be the ejection charge gas bulkhead.
10. Lightly sand the open edge of the PIN-50Y and spacer tube. Then carefully align and bond the ply disk to this edge.
11. Apply thin cyanoacrylate to the exposed face of the disk to seal it against gas flow.



12. Cut a 4.0" length of BT-50 tubing. Pierce the tube in 3 places, spaced at 120 degrees, 0.94" from one end of the tube.
13. As with the BT-20 tube, use a 1/8" drill bit to carefully round out each pierced hole. Again apply thin cyanoacrylate around the edge of each hole and allow to cure. Then lightly sand the interior and exterior surfaces of the tube at the hole edges to make them nice and crisp. Run the drill bit through the holes again to remove any fuzz.
14. Bond the base adapter assembly inside this end of the payload section with the holes.



15. Remove the attachment loop from the remaining PIN-50Y adapter. Lightly sand the face of the part smooth, and then bond the adapter inside the base of the PNC-50Y nose cone.




This completes the assembly steps for the altimeter test payload section.

Test fit the inner BT-20 altimeter holder tube into the BT-50 tube. Insert the EZ675-5K into the holder tube with the transducer at the lower adapter end.

Always remember to install the altimeter in the payload section with the pressure sensor at the forward end.

The payload section is designed so that the bottom printed circuit board edge stops at the edge of the EB-20A engine block. Test fit the nose cone into the forward open end of the tube. The fit must be tight so the altimeter isn't ejected during deceleration or at the shock of parachute opening. Use layers of masking tape around the nose cone adapter to achieve the needed tight fit.



Phantom View Of EZ675-5K Inside Payload Section

You can paint the exterior of the completed payload section almost any way you like. However, do NOT paint it black or other dark color. Dark colors will heat the interior of the payload in sunlight and this is to always be avoided.

In use, make sure the pressure vent ports are never obstructed in any way. Keep your back toward the sun when handling and inserting the EZ675-5K in the payload section. Direct sunlight can adversely affect the way the pressure sensor operates, and is why the suggested payload section is designed to block it.

When planning other payload section designs, always try to follow the '3 X 3' rule – place three equally spaced holes in the body section placed at a minimum of 3 calibers aft of the nose cone / body tube joint. The use of the 3 holes helps to eliminate any false threshold triggering during handling or on the launch pad waiting for launch. They also help minimize any pressure variations on all sides at any orientation of the rocket during flight.

Always make sure the vent holes have clean and smooth edges on any payload section you build. Use the technique described in the payload section construction above for piercing, drilling, and sealing the hole's edges. Try to make the diameter of the holes approximately 8% - 10% of the diameter of the payload section.

Operation of the EZ675-5K Altimeter

The user should always follow a specific order of flight preparation sequence when using the EZ675-5K. Take a few more moments to double check each step before launch. Otherwise, the altitude readings may be incorrect.

- 1.** Start by removing the nose cone or forward closure from the altimeter payload section. Also remove the altimeter holding fixture from within the payload section if used.
- 2.** Prepare the rocket for flight in normal fashion. Select and install the motor with igniter. Insert the proper amount of flameproof wadding. Roll, fold and insert the parachute(s), then temporarily mate the empty payload section to the main power section.
- 3.** Insert the 12 volt A23 battery to turn the altimeter ON. The altitude of the previous flight will be reported two times. This indicates the altimeter is operating correctly. Once this is confirmed the user can begin the process of installing the altimeter in the payload section.
- 4.** Use caution not to install the altimeter too quickly. The air in the payload section must be allowed to exit freely to prevent false launch site readings as the altimeter is slides into position. This can occur if altimeter installation spans the silent 15 second launch site pressure measuring mode.
- 5.** When the 15 second period ends the altimeter will indicate readiness with a short "beep" repeated every 1.5 seconds. At this point the rocket is ready to launch.

6. Reinstall the nose cone or forward payload section closure. Place the rocket on the launch pad, attach the igniter power leads, and prepare for launch in the typical fashion.

When the rocket is recovered after flight, the EZ675-5K will be reporting the peak altitude attained. Since this reading is saved in memory, there is no rush to remove the altimeter from the payload section to hear and record the altimeter reading. If desired, the user can open the payload section and remove the battery to hear the altitude at a later time. Otherwise, listen and record the altitude reached as displayed by the transducer.

Reminders:

- Avoid touching the circuit board traces or components when powered.
- Avoid allowing any metallic object to touch the altimeter when powered.
- Protect the altimeter from severe temperature fluctuations before operation.
- Avoid strong wind gusts flowing past the altimeter payload section prior to launch.
- Always protect the altimeter pressure sensor from direct sunlight.
- Do not allow the altimeter to come in contact with water.
- Replace the battery when the voltage falls to under 7.0 volts.
- Protect the pressure sensor from excessive pressures.
- Always follow proper operational sequencing as listed in preflight checklist.

Warranty

The purchase of an EZ675-5K altimeter includes a 90 day warranty against defects in parts and workmanship. Your EZ675-5K will be replaced if it should fail in use during this time period. This warranty applies only to the altimeter, and does not cover any rocket, rocket motors, or any other part, parts, and any other equipment associated with the use of the EZ675-5K altimeter.

Not covered by this warranty is damage due to misuse, mechanical or circuitry alterations, and failures caused by use outside of the recommended operating conditions. Any damage to the pressure sensor caused by diaphragm puncture or pressure sensor damage caused by ejection charge pressure or heat, are not covered under this warranty.

Liability

This product has been designed and constructed with the highest quality materials. As the installation, setup, preparation, maintenance, and use of this product is beyond the control of the manufacturer, the purchaser and user accept sole responsibility for the safe and proper use of this product.

The principals, employees, and vendors of the manufacturer shall not be held liable for any damage or claims resulting from any application of this product. If the purchaser and user are not confident in their ability to use the product in a safe manner it should be returned to the point of purchase immediately. Any use of this product signifies acceptance of the above terms by the purchaser and user.